




## Installation Guide Mini 60 - US



Material	High Strength Reinforced Nylon
Colour	Black
Fixing Method	Glue




Set the depth stop to #20 and guide height for substrate thickness. Plunge in once then repeat using the **Mark-Out Template**, packing the guide 0.118" to achieve a 0.276" cut.




To aid in the installation of the Key and Hook, start by inserting one end in the slot when use a hammer or mallet to tap the component into place. Ensure centre lines on substrate align with centre marks on Hook and Key.


## Mounting




Use a Ø9/32" router bit to cut a slot in both substrates where the Hook and Key of the Mini 60 is to be mounted. Depth needs to be 0.394" for each.




Apply Striplox Liquidlox 15 second cure adhesive to both sides of the slot in each substrate. Visit joinlox.com/striplox or call 1800 JOINLOX to find out more about Striplox Liquidlox and Mark-Out Template.




After glue is applied, insert Key and Hook into slot until flush with substrate. Allow to dry as per glue manufactures instructions.




The Mini 60 features locating tabs which click into place when fully assembled. Please note this feature is not a lock, making the joint fully reversible.



Assembly components remembering the Key only needs to travel 1 pitch for full engagement. This is detailed in steps A and B.




Note the offset of the lugs on the Key body, length X is larger than Y. Insert the Hook into the Key with the longer X end towards the face to be pushed during assembly.



To complete the assembly push the end of the substrate (with X offset) until the Mini 60 is fully engaged.

### **Load Capacity**



Direction	Indic. Load Capacity
А	198 lb
В	176 lb
*C	220 lb


- Tested using MDF and fixed with glue.
- \*C is in direction of lock-up.


## Striplox Mini 60 Rapid Assembly Systems



## Mounting Data Sheet - US Version *All dimension in inches*

#### **General Dimensions**






Material	High Strength Reinforced Nylon
Colour	Black
Fixing Method	Glue

#### **Mounting Dimensions**

#### Option A - Router Cut




#### Notes:


- 1. Groove detail typical for both Hook and Key halves.
- 2. Key shown in groove.

## STRIPLOX™ JOINLOX® ARE TRADEMARK AND PATENT PROTECTED INTERNATIONALLY Striplox Mini 60 Mounting Data Sheet - US 1.0

#### Option B - Biscuit Cutter




(1) #20 biscuit cutter depth setting




(2) To obtain the required 0.276" cut use the <u>Striplox Mark-Out</u>
<u>Template</u> as a packer in conjunction with a standard biscuit cutter.




## Installation Guide Mini 120 - US




Material	High Strength Reinforced Nylon
Colour	Black
Fixing Method	Glue




Set the depth stop to #20 and guide height for substrate thickness. Plunge in 3 locations then repeat using the **Mark-Out Template**, packing the guide to achieve a 0.276" cut.




To aid in the installation of the Hook and Key, start by inserting one end in the slot when use a hammer or mallet to tap the component into place.




Use a Ø9/32" router bit to cut a slot in both substrates where the Hook and Key of the Mini 120 is to be mounted. Depth needs to be 0.394" for each.




Apply Striplox Liquidlox 15 second cure adhesive to both sides of the slot in each substrate. *Visit joinlox.com/striplox or call 1800 JOINLOX to find out more about Striplox Liquidlox and Mark-Out Template.* 




After glue is applied, insert Hook and Key into slot until flush with substrate. Allow to dry as per glue manufactures instructions.




Before assembling the Striplox Mini 120, make note of the locking tab on the Key. Leaving this tab in place will prevent the unintentional unlocking of the joint.



Assembly components remembering the Key only needs to travel 1 pitch for full engagement. This is detailed in steps A and B.




Note the offset of the lugs on the Key body, length X is larger than Y. Insert the Hook into the Key with the longer X end towards the face to be pushed during assembly.



To complete the assembly push the end of the substrate (with X offset) until the Mini 120 is fully engaged.

### **Load Capacity**



Direction	Indic. Load Capacity
А	440 lb
В	322 lb
С	262 lb


- Tested using MDF and fixed with glue.
- \*C is in direction of lock-up.


# Striplox Mini 120 Rapid Assembly Systems



Mounting Data Sheet - US Version All dimension in inches

#### General Dimensions








Material	High Strength Reinforced Nylon
Colour	Black
Fixing Method	Glue


#### Mounting Dimensions



- 1. Groove detail typical for both Hook and Key halves.
- 2. Key shown in groove.

STRIPLOX™ JOINLOX® ARE TRADEMARK AND PATENT PROTECTED INTERNATIONALLY Striplox Mini 120 Mounting Data Sheet - US 2.1

## Option B - Router Cut



### Option C - Biscuit Cutter

