

# Glideware<sup>TM</sup>

## Glideware Installation Instructions for a single face frame cabinet

Watch the installation video at: [www.glideware.com](http://www.glideware.com)

### What is Included:

- Glideware Organizer
- Installation instructions
- Hooks
- Bag that includes:
  - 1-1/4" screws
  - 1-1/2" screws
  - drill bit
- Mounting bracket



### What You Need to Install:

- Screw gun
- Tape measure
- Pencil



### Prepare your Cabinet:

Remove shelving or pull out drawers from the cabinet.  
Make sure that your cabinet is clear before installing Glideware.

800-558-9947 [www.glideware.com](http://www.glideware.com)

PATENT PENDING





Watch the installation video at:  
[www.glideware.com](http://www.glideware.com)

|  |  |   |
|--|--|---|
| <p>1. Measure the opening at the top of the cabinet, find the center, and make a light pencil mark on the cabinet</p>  | <p>2. Measure the distance from the <b>INSIDE</b> bottom of the base cabinet to the bottom of the upper portion of the face frame. Transfer that measurement to the back inside of the cabinet. Make the mark at approximately the center of the cabinet</p>   | <p>3. Measure 2 ¼ inches down from the mark on the back of the cabinet and make a new mark. Measure the width of the cabinet to find the center and intersect the new mark</p>  |
| <p>4. Locate the mounting bracket and mark the center bottom of the bracket. (Bracket right side up should resemble an “F”). Take that mark and line it up with the intersected mark on the back of the cabinet. While holding the mounting bracket on the back of the cabinet, level the bracket and trace a horizontal line underneath the entire width of the bracket. (This will help you locate the position of the mounting bracket for the next step)</p> | <p><b>Tip!</b><br/>Before attaching the mounting bracket, preset the 1 ¼” screws into the front of the pre-drilled holes until they slightly protrude from the back of the bracket</p> <p><b>Optional:</b><br/>You may choose to apply silicone to the back of the mounting bracket</p>                                  | <p>5. Place the mounting bracket on the back of the cabinet. Align the bottom of the mounting bracket with the horizontal line that was made in (Step 4). The screws that are protruding from the back of the mounting bracket will be located inside of the pre-drilled holes on the back of the cabinet</p>   |
| <p>6. While pressing the mounting bracket against the back of the cabinet, ensure that the screws are positioned over the pre-drilled holes. Fasten the bracket to the cabinet by tightening each of the screws until snug</p>   | <p>7. Locate the Glideware unit and remove the centerpiece by fully extending, push down the lever on one side and pull back the glide. Do the same for the other side. Remove centerpiece</p>   | <p>8. Make a center mark on the front of Glideware unit</p>   |
| <p>9. Slide the back of the Glideware unit into the mounting bracket and line up the center mark on the front of the cabinet with the center mark of the front of the unit</p>   | <p>10. While holding the Glideware unit against the bottom of the upper part of the front of the cabinet (<u>Ensure that the front of Glideware is FLUSH with the face of the cabinet and the two marks are aligned</u>). Using the drill bit provided, pre-drill cabinet through the holes in the front of the unit</p> | <p>11. Gently fasten the unit to the front of the cabinet using the (2) 1 ½” screws provided</p> <p><b>Important!</b> - <u>Do not over tighten, this could split the wood</u></p>   |
| <p>12. Fully extend the glides out from the unit, while holding the glides on the unit in place, align the centerpiece and slide the glides into the associated slots in the unit. Push the centerpiece inward until it “clicks”. Repeat for the other side</p>  | <p>13. Push the centerpiece in towards the cabinet completely until closed.</p> <p>Note: Initially you may feel resistance but once “seated” it will operate smoothly</p> <p><b>Place your hooks in any arrangement that works for you, hang your ware and enjoy!</b></p>  | <p>Glideware may also be fastened directly to the counter sub top or to the top of the cabinet, such as a frameless cabinet style. Be sure that there is clearance for Glideware to operate with out interference</p> <p>Tip: For Dual-ing Glideware installation, measure largest item to hang on each side and space Glideware accordingly. (To get the most out of your space hang all larger diameter items on one side and smaller on the other)</p> <p>For additional installation instructions please email <a href="mailto:info@glideware.com">info@glideware.com</a></p> |