


## Slide installation

### Mounting full-extension runner on cabinet side




See **screws**, page 38.


Elongated holes are for  $\pm 4.5 \text{ (3/16")}$  **depth adjustment** only. Additional screws must be used to secure the runner to the cabinet.

Elongated holes are for  $\pm 6 \text{ (1/4")}$  **vertical adjustment** only. Additional screws must be used to secure the runner to the cabinet. Only with frameless application or face frame application with filler.



### Drawer slide assembly Face frame application without filler behind frame



### Drawer slide assembly Face frame application with filler behind frame Frameless application




## Drilling patterns - Standard face frame cabinet member




Note: orange dots indicate fixing screw locations and quantity to meet load ratings.

### Mounting to the cabinet side - Runner lengths 381, 457 and 533 mm




**Face frame application without filler behind frame**

**Use of rear sockets for any load above 75 Lbs is not recommended**




**Face frame application with filler behind frame**

Sockets and brackets can be used for the correct alignment of the runners before fixing to the cabinet side.




**Frameless application**

## Drilling patterns - Short version cabinet member




Note: orange dots indicate fixing screw locations and quantity to meet load ratings.

### Mounting to the cabinet side - Runner lengths 457, 533, 610, 686 and 762 mm




Face frame application with filler behind frame



Frameless application

Use of at least 4 fixing screws to the side is highly recommended. For these runner lengths rear brackets and sockets cannot be used. Cabinet sides must be blocked. On longer lengths load capacity may vary.


## Technical information - Drawer settings




**Face frame application  
without filler behind frame**

### DRAWER SETTING ABBREVIATIONS:

- SP** = Drawer side thickness
- LN** = Nominal runner length
- PM** = Cabinet depth
- X** = Cabinet internal width
- LC** = Drawer length




**Face frame application  
with filler behind frame**



**Frameless application**

## Drawer dimensions and drilling

Full-extension runner for 12 mm (1/2") to 16 mm (5/8") drawer material




### Rear hook



Use **SGD704UGXA drilling template** for rear hook, see page 34.

### Drawer back preparation



**F70 Push Synchronizer**, see page 30.

**AGLRXX3F tilt adjustment lever**, see page 37.